SWIFT DocK ®

# Installation guidelines
# for Swift-Dock with PCB fitted
Applicable for both spring contact and contact land side

Fitting

Always fit from the rear of the panel

Nut and bolt or self tapping screw fitment

Moulding or enclosure

Part No. SWIFT-DOCK-4P-SC

Soldering

- Attach the cables prior to fitting if possible.
- Use suitable cable size for the PCB holes which are 1.0mm in diameter.
- Use the two large holes in the PCB to anchor the cables with cable tie.

Part No. SWIFT-DOCK-4P-SC